

ATMOR

Hot Water on Demand

INSTANT WATER HEATER

InLine

HIDDEN INSTALLATION

900 Series



Directions of Assembly and Operation of "In-Line" Instant Water Heater

"Instant" appliance is a novel device designed to supply hot water instantaneously upon demand while conserving electricity, water and energy.

The "In-Line" is the most advanced heater in the "Instant" family and as such can be installed anywhere, and serve any purpose. When the flow switch turns on the electrical current, the heating element heats only the amount of water economically needed for use.

OVERVIEW

This manual must be read carefully before attempting to install the water heater. If you do not follow the safety rules or the instructions outlined in this manual, the unit may not operate properly and it could cause property damage, serious bodily injury or death.

Atmor will not be liable for any damages because of failure to comply with the installation and operating instructions outlined in this manual or because of improper use. Improper use includes the use of this appliance to heat any liquid other than water. Failure to comply with the installation and operating instructions or improper use voids the warranty. Never remove the unit's cover unless the electricity is turned off.

SAFETY PRECAUTIONS

Please read and follow these instructions. Failure to follow these instructions could result in serious bodily injury or death.

The unit must be installed by a licensed electrician / plumber. The installation must comply with all national, state and local plumbing and electrical codes.

Service of the unit must be performed by qualified service technicians.

Before proceeding with any installation, adjustment, alteration, or service of this unit, all circuit breakers and disconnect switches servicing the unit must be turned off. Failure to do so could result in serious personal injury or death.

Danger: Never remove the unit cover unless the electricity servicing the unit is turned off. Failure to do so could result in personal injury or death.

Warning: The unit must be properly grounded. Failure to electrically ground the product could result in serious personal injury or death.

Warning: Unit must be installed with the plumbing connections pointing downward only.



Warning: Do not install unit where it would routinely be splashed with water. Electric shock or death may result.

NOTE: If soldering near the unit is necessary, please direct the flame away from the housing of the unit, in order to avoid damage. Excessive heat from soldering on copper pipes near the unit may cause damage. All plumbing work must comply with national and applicable state and local plumbing codes.

INSTALLATION INSTRUCTIONS

This water heater must be installed by a licensed electrician, as required by law.

1. Open the four screws located on the top and bottom of the device and remove the cover from base.
2. Fix the base horizontally against a wall or side of cabinet, **metal plate supplied must be installed below cable entry on the wall and ground wire must be connected to the unit**, the water entry and exit connectors are on the down/bottom side of the unit. Use 4 mounting screws provided.



3. For the AT900-13 model, use the supplied water filter on the income water line (see attached separate diagram: "Water filter installation").
4. Connect the incoming water line (cold only) on the bottom left side and the outgoing water line to the bottom right side. Please check that there is no water leakage from the unit.
5. Connect and lock the electric lines to each corresponding connector. It is required that this device be properly grounded.
6. Turn on the unit and check that it is operating as required.
7. Reconnect the cover to the base with 4 screws.
8. It is required that a Ground Fault Circuit Interrupter/Earth Leakage Circuit Breaker be incorporated in the circuit.
9. Make sure that there is a pressure release valve in your water system.
10. It is required to install a flow control restrictor (AERATOR) at the sink or shower.

**WARNING: UNIT MUST BE PROPERLY GROUNDED
THIS HEATER MUST HAVE ITS OWN INDEPENDENT CIRCUIT USING
A CORRECTLY RATED CIRCUIT BREAKER AND SUITABLE WIRE, SEE
TABLE RECOMMENDED CABLE.**

OPERATION INSTRUCTIONS

1. Your new Instant Water Heater is flow activated. Simply place one or both switches in the ON position and turn on the hot water tap. You will need to allow at least 1.5 liters per minute to flow through the unit in order to activate the Instant Heating System. Run water through the heater for a few minutes.
2. Be sure to every so often clean the spray head of sediment to assure a smooth water flow.
3. Be sure to every so often clean the incoming water filter.
4. The maximum operating water pressure is 8 atmospheres or 115 PSI. This is well above the usual 3 atmospheres or 40 PSI most municipal water systems provide.
5. Be sure to install your Instant Water Heater in a heated location. It cannot be installed where temperatures drop below freezing.
6. There are two ways to adjust the hot water temperature. One is by adjusting the flow, the other is by changing the electrical settings on the unit. The slower the flow, the more time the unit has to heat the water, resulting in higher water temperatures. Adding more rings to the water flow restrictor will limit the flow and increase the output water temperature. You may choose the low, medium or high settings on the heater, as required to achieve the water temperature desired.

Setting 0/OFF: No heating, lamp will not light.

Setting 1: Low heating, lamp 1 will light.

Setting 2: Medium heating, lamp 2 will light.

Setting 3: Maximum heating, both lamps will light.


For 220V - 240V 3.5kW unit only positions 0 & 1 are available.

7. During the summer, it is recommended using only setting 1 or 2 for device with 220V-240V 13kW output.

INSTALLATION REQUIREMENTS


- A. A separate electrical line is required.
- B. The device must be connected to a separate circuit breaker.
- C. The recommended electrical cable for feeding the device, see table I (next page).

Device below a sink with 110V up to 3.5kW output and 220V-240V 3.5kW-8.6kW output



1. Terminal block
2. Thermal cut-out with reset
3. Thermal cut-out
4. Relay
5. Light
6. Switch 0- Off
(Option) 1- Low
7. Heating element
8. Read sensor

Device below a sink with 220V - 240V 8.6kW-10.6kW output




1. Terminal block
2. Thermal cut-out with reset
3. Thermal Cut out
4. Relay
5. Switch 0- Off
1- Low
2- Medium
3- High
6. Heating element
7. Read sensor
8. EARTH(G) Connection in the heating canister

Device with 220V-240V 10.6kW- 13kW output

- A. A separate electrical line is needed as power supply for this device.
- B. The device must be connected to a separate circuit breaker.
- C. The recommended electrical cable for feeding the device, see table I.


- 1. Terminal block
- 2. Thermostat with reset
- 3. Thermostat
- 4. Switches with lights
- 5. Relay
- 6. Heating elements
- 7. Read sensor
- 8. EARTH(G) Connection in the heating canister



WARNING!

BEFORE BEGINNING ANY WORK ON THE ELECTRICAL INSTALLATION BE SURE THAT THE CIRCUIT BREAKER IS IN THE "OFF" POSITION TO AVOID DANGER OF ELECTRICAL SHOCK

CORRECT INSTALLATION



INCORRECT INSTALLATION



TABLE I: RECOMMENDED CABLE

Model	V ac	kW	AMPS	Min Field Wire (AWG)	Min Ground Wire (AWG)	Model	V ac	kW	AMPS	Min Field Wire (AWG)	Min Ground Wire (AWG)
3.0N-110	120	3.5	30	10+	10+	6.0N-220	240	6.0	25	10	10
3.8N-110	120	4.4	37	6+	10+	6.5N-220	240	6.5	27	10	10
						8.5N-220	240	8.5	35	6	10
3.5N-220	240	3.5	15	14	14	9.5N-220	240	9.5	40	6	10
3.8N-220	240	3.8	16	12	12	10.5N-220	240	10.5	44	6	10
5.5N-220	240	5.5	23	10	10	11.0N-220	240	13.0	55	4#	8#

Not specified = Cooper wire to be rate min 140 F°
 + = Cooper wire to be rate min 167 F°
 # = Cooper wire to be rate min 194 F°

- Operating water pressure 0.5-10 bar (7-145 psi)
- Water pressure operated flow switch
- Standard 1/2"Ø compression inlet connection
- Top-left and right cable entry
- Bottom-left water entry

UNIT DIMENSIONS: HEIGHT 7.3in WIDTH 11.8in DEPTH 3.55in

TECHNICAL INFORMATION

item no.	AT900-04	AT900-06	AT900-08	AT900-10	AT900-13	AT900-03
Phase	1	1	1	1	1	1
Voltage	240	240	240	240	240	110
Wattage (KW)	3.8	6.5	8.5	10.5	13	3
Amperage	16	27	36	44	55	27
Circuit breaker size	20	30	40	50	55	30
Required wire size (min)	12 AWG	10 AWG	6 AWG	6 AWG	4 AWG	10 AWG
Minimum water flow to activate unit	0.5 GPM					
Weight (lb)	3.4 lb					
Dimensions (in) (HxWxD)	7.3x11.8x3.55	7.3x11.8x3.55	7.3x11.8x3.55	7.3x11.8x3.55	7.3x11.8x3.55	7.3x11.8x3.55
Nominal water volume	0.11gal / 0.42l					
Working pressure	8 bar (115psi)					
Texted to pressure	16 bar (230psi)					
Water connections	1/2" NPT					

MODEL GUIDE

Model	240V	208V	110V	120V
AT900-04	3.8 kW	2.8 kW	-	-
AT900-06	6.5 kW	4.9 kW	-	-
AT900-08	8.5 kW	6.4 kW	-	-
AT900-10	10.5 kW	7.9 kW	-	-
AT900-13	13.0 kW	9.8 kW	-	-
AT900-03	-	-	3.0 kW	3.5 kW

TROUBLESHOOTING GUIDE

Your water heater has no internal user serviceable parts and should be returned to the factory for repair or replacement. Please contact toll - free hot line for return authorization.

If after following the Installation Instructions, your Instant heater does not heat water in accordance with this literature, please check the following:

Symptom	Possible Cause	Solutions
No hot water despite fully open hot water faucet	No electrical power.	Check the circuit breaker and Voltage at the wiring block.
	Low Voltage / Low Power	Verify your voltage by using a voltage meter. You should obtain your reading off the two outside terminals located on the heater. Compare the reading against the voltage specified in the Installation Instructions. The center terminal is always the earth ground.
	Length of Pipe	Length of pipe run will affect the temperature increase. The heater should be mounted No more that 12-18 inches from the point of use.
	Flow Rate	Controlling flow rate is essential to insure proper temperature increase. Check your flow rate to insure proper operation of the heater.
The activation flow rate Needed to turn on the heating Element has not been reached	Low flow rate	In the case of the low flow rate heater, it is mandatory that the flow control be attached to the end of the faucet. Clean filter screen - turn circuit breaker off - open hot Valve to release Pressure from the unit. - Check shut-off valve and make sure valve is open 100% to allow full water pressure to the heater - turn circuit breakers on. Standard Flow Rate Models require 0.5GPM to activate.
No running water from the unit	Freezing	Instant heaters must be drained and stored if installed in a location subject to freezing. Disconnect the inlet/outlet compression fittings and blow air through one side of the heater to assist draining.

• **Problems?** - Call our toll-free hotline (888) 783-6082 Ext. 311.

LIMITED WARRANTY

Atmor warrants to the original owner that our instant water heaters will be free from defects in workmanship and material for a period of TWO YEARS from the date of purchase, and free from leakage for a period of SEVEN YEARS from the date of purchase. Should any part(s) prove to be defective during this period, Atmor will be responsible for replacement of the defective part(s) only.

Atmor is not responsible for labor charges or any incidental or consequential expenses.

Should the owner wish to return the water heater for repair, the owner must first secure a written authorization from Atmor. The owner shall be required to show proof of purchase date and to pay all transportation costs to return the defective part(s) or water heater for repair or replacement. Warranty is void if: (i) water heater has been installed or used improperly; (ii) design has been altered in any way; (iii) water heater has been installed and/or serviced by someone other than a licensed electrician ; (iv) or if the water heater has been installed or used in contradiction to installation instructions, applicable laws and/or ordinances.

Distributed by:

PARAGON GROUP USA - LLC

15 Engle Street, 3rd Floor

Englewood, NJ 07631

(201) 266-6775