

anchors (C) in the holes

7. If mounting to a stud, drill holes with 1/8" drill bit

8. Return the unit to the location, and secure in place with screws (D).

- (18.125 left to right, and 7.875 front to back).5. Mark a center point between the back two holes.
- 6. Drill 5 holes using the 1/8" drill bit.
- 7. Return the unit, and secure in place with screws (A and B).