

Instructions / Directions

1U Flanged Spacer Blank

1901-1-001-01



For details about product warranty, please visit www.kendallhoward.com

www.kendallhoward.com

KENDALL HOWARD  TM
INNOVATORS IN PRODUCT DESIGN

Address: 10152 Liberty Lane
Chicago City, Minnesota, 55013
United States of America

Phone: 651-213-1333

Fax: 800-418-6897

DISCLAIMER: Kendall Howard LLC. endeavors to make this manual accurate and complete. However, Kendall Howard LLC makes no representations or warranties of any kind, expressed or implied, about whether the use of products contained herein would infringe any rights or the correctness, accuracy or reliability of the information contained herein or that said information covers all details, conditions or variations. The information herein does not provide for every possible contingency in connection with the installation or use of the product(s). The information contained in this document is subject to change without notice or obligation. Kendall Howard LLC assumes no responsibility for the accuracy, completeness or reliability of the information contained in this document. Any reliance placed on the information is therefore strictly at your own risk.

Tools Needed:

Screw Driver



You may also need:



Assembly - Step 1:



If using cage nut rails, install Tool-less Fastener and / or rack screws on each end of Spacer Blank. If using tapped rails, install with rack screws.

Included:



1x / 1U Flanged Spacer Blank

2x / Tool-less Fastener



Assembly - Step 2:



Secure Tool-less Fasteners. If rack screws are used, secure them with screw driver.

2

3