

ANODIZED SEAT BOARDS

- MILL FINISH FOOTBOARDS

TREAD ENDCAPS ARE PLAIN.

-SEAT ENDCAPS TO HAVE

I. LOCATE THE CHANNEL END CAP AS SHOWN, WITH THE WIDER FLANGE ON

2. TAP THE CHANNEL INTO PLACE WITH A RUBBER MALLET OR SOFT WOOD.

3. DRILL (2) No.8 x 3/4" TEK SCREWS THRU END CAP AND BOTTOM FLANGE OF PLANK

4. ENDCAPS WITH STICKERS ARE TO GO AT ENDS OF SEAT PLANKS, PLAIN ENDCAPS GO

TIE DOWN CLIP (T48) w/ 5/16" X 1-1/4" CARR BOLT & FLANGENUT (C56114) TYPICAL

_	
	2810 Sydney Road Plant City, Florida 33566 Phone: 813-305-1415 Fax: 813-305-1419 A PLAYCORE Commun. www. gtgrandstands.com
	SEATING PLAN 2 ROW BLEACHER TIP -N- ROLL
	NR-022IAD-TR AND NR-022IGD-TR
-	DRAWN BY CHECKED BY DATE MAR 2010 SCALE NOTED JOB NO. NR-0221AD-TR NR-0221GD-TR DWG NO. 1 of 1