



ASSEMBLY INSTRUCTIONS

1 Twist off the wing nut and remove the washer from the bolt.



2 Slide the handle in between both braces and onto the bolt. Place the washer on the bolt, then screw on the wing nut.



3 After screwing on the wing nut, line up both braces together on the handle.



4 Slide the lock down the handle.



5 Screw the lock onto the braces.



6 Remove the packaging. Ready to sweep.

