

Afford-A-Wall with Wheels Assembly Instructions

- Phillips screwdriver
- 9/16" wrench



Step #1 Remove 9/16" bolt from bottom of partition

Recommended Tools



Step #2: Add caster base and re-insert 9/16" bolt.



Step #3: Use a 9/16" wrench to tighten bolt.



Step #4 Insert two Phillips head screws into side of caster base, and tighten with screwdriver.



Step #5 Repeat steps 1-4 for the second caster base.