

MP10 Assembly Instructions

- Cordless drill with Phillips bit (or standard Phillips screwdriver)
- Rubber hammer
- Scissors or utility knife.

Recommended Tools



Step #2: Remove strap from the first and last panel as shown. Do not remove the strap holding the partition assembly.



Step #4 Remove Casters from box, install as shown in steps 7 & 8.



Step #1 Remove the Partition from the box.



Step #3: Remove box containing hardware and casters.



Step #5 Attach loose panel with triangular bracket as shown.

MP10 Assembly Instructions



Step #6: Rotate the partition assembly to rest on the installed panel, and repeat for the remaining loose panel.



Step #7: Install 4 of the casters as shown into the bottom corners of the two newly installed panels.



Step #8: Install the remaining 4 casters as shown above.



Step #9: As shown above, rotate the partition on its wheels.



Step #10: Remove the straps holding the partition assembly together.



Step #11: Open the partition and begin using.