

# Series 100 Dock Seal Installation Instructions

## Hardware

Your *Dor-Seal* was purchased with the intent to be mounted so that its vertical pads are either flush with or offset from the door jamb.

If the *Dor-Seal* vertical pads are to be mounted flush with the doorjamb, each unit will contain the following:

6	90° Angle Bracket
6	Flat Brackets
24	5/16" x 1 ½" Screws

If the *Dor-Seal* vertical pads are to be mounted offset from the doorjamb, each unit will contain the following:

10	90° Angle Bracket
2	Flat Brackets
24	5/16" x 1 ½" Screws

## Install Directions

- 1) Attach two (2) 90° angle brackets on the outside of each pad, being sure to firmly attach the brackets to the lumber backing of the seal using two (2) screws per bracket.
- 2) Anchor vertical pads on the building face, so the opening between pads is the desired width.
- 3) Attach two (2) Flat brackets (if flush mounted) or two (2) 90° angle brackets (if offset mounted) to the inside of each vertical pad. Using two (2) screws per bracket.
- 4) Anchor inside of vertical pad to doorjamb of building face.
- 5) Follow exact same instructions with head pad – install brackets and anchor to building.

