


Kit # 4560-P Kit, Rim Clamp Assembly

Operator's Manual for Morse Rim Clamp Assembly Kit

Kit # 4560-P Serial number 0615 to ____ (MMYY)



INSTALLATION INSTRUCTIONS for MORcinch Drum Holder

- Position Rim Clamp Assembly (item 1) on drum holder bracket with holes aligned.
- Bolt in place using 2 bolts (item 5) and 2 nuts (item 4).

INSTALLATION INSTRUCTIONS for Drum Holder with Socket Tube

- Slide Rim Clamp Assembly (item 1) down through socket tube, and line up top holes in Rim Clamp Assembly with top holes of socket tube.
- 2. Use bolt (item 6) and nut (item 4) to bolt in place through the top holes of the socket tube and the Rim Clamp Assembly.

ITEM	QTY	PART #	DESCRIPTION
1	1	5806-P	WELD, RIM CLAMP
2	1	3616-P	HANDWHEEL ASM, 4", 3540-P 185R
3	1	3510-P	THREADED BARREL, RIM CLAMP
4	2	1169-P	NUT, 3/8-16 REV HEX LOCK
5	2	82-P	HHCS, 3/8-16 X 2-1/4 GR2
6	1	1315-P	HHCS, 3/8-16 X 2-3/4 GR2

MORSE Mfg. Co., Inc. Phone: (315) 437-8475

727 West Manlius Street

P.O. Box 518

East Syracuse, NY 13057-0518

Fax: (315) 437-1029

Email: service@dorsedrum.com

Website: morsedrum.com



PART # 4560-P Kit, Rim Clamp Assembly

Operator's Manual for Morse Rim Clamp Assembly Kit - Part # 4560-P Serial Number 0615 to ____ (MMYY)

OPERATING INSTRUCTIONS

TO SECURE DRUM:

- 1. Turn hand wheel (item 2) counter clockwise to open top jaw.
- 2. Position drum holder assembly with bottom jaw of rim clamp directly under top rim of drum.
- Turn hand wheel clockwise until top jaw is pressing tightly against top of drum (see Figure 1).
- Secure drum with chain and ratchet mechanism. Drum is now ready to be lifted and tilted.

TO RELEASE DRUM:

- 1. Lower drum to floor in an upright position.
- 2. Release chain from ratchet mechanism by applying pressure to ratchet handle in a clockwise direction with one hand and opening pawl to free ratchet with other hand. Remove chain link from ratchet.
- 3. Open rim clamp by turning hand wheel counter clockwise.




Figure 1 Plastic drum being lifted with Rim Clamp Assembly Kit installed.