

360° Panaramic® Dome Mirror INSTALLATION INSTRUCTIONS



1. Note: If wires seem to be loose at centered washer, additional tension maybe created by squeezing inverted "U" area of wire (in center of each wire with pliers).
2. Mirror can now be hung with any cord, wire or chain.
3. Attach cord to center washer.
4. To level mirror, attach second cord to lowest end of mirror at inverted "U" area of wire and tie other end of leveling cord to midpoint of center cord.