

NATURAL GROUND MOUNTING INSTRUCTIONS by FLEXPOST®

Tools Required:

- Rubber Mallet or Hammer and a Wood Block
- 3/4" Ratchet Wrench
- 3/4" Wrench

Pieces Included:

- Natural Ground Spike
- Spring
- Spring Hardware—Two bolts, two locknuts, four washers
- Post

1



- Identify desired mounting location.
- Using a rubber mallet, tap the spike into the ground until the ring is flat against the ground. If you use a hammer instead, place a wood block between the hammer and spike to prevent damage to the stem.

2



- Using the wrench and ratchet, attach the spring to the stem of the ground spike with the included spring kit.

3



- Insert the post into the other end of the spring and attach them using the remaining hardware in the spring kit.

4



- Please allow 24 hours for ground to settle for maximum stability.

***Note: For a more permanent application, use a post hole digger to dig out a hole 24" deep. Fill the hole with quick set cement. Place spike into the cement and allow appropriate dry time.**

FLEXPOST® 

4190 Sunnyside Drive
Holland, MI 49424 USA
Phone (866) 577-2588 or (616) 928-0829
Fax (616) 928-1138

CAUTION: Check Underground Utilities Before Installing Natural Ground Anchor!