


# Lumina Reversible Boards



**Assembly Instructions** 

#### **Lumina Reversible Boards**

Part	Drawing	Description	Qty	Part	Drawing	Description	Qty
			1 EA	Hardware List			
P-1		Board Assembly		А	Θ	Screw M6X20mm	10 EA
				В		Non-Locking Caster	2 EA
				С	O	Locking Caster	2 EA
P-2		Leg	2 EA	D		Allen Wrench	1 EA
		<b>&gt;</b>		E		Caster Wrench	1 EA
P-3		Top Cross Brace	4 5 4	F		Knob	2 EA
			1 EA	G		Hinge Pivot	2 EA
				Н		Lock Washer	4 EA
P-4		Bottom Cross Brad	e 1EA		(	you require assist during assembly, all our Customer S	
P-5		Tray	1 EA	Department Monday - Friday 8 a.m 5 p.m. Central Standard Time 1-800-749-2258			
P-5							

## **Important**


The Balt product you have purchased is guaranteed against material and workmanship defects. This guarantee extends 1 year from date of purchase. Should this product fail to function satisfactorily under normal use due to defect or imperfection, the defective part or product will be replaced. Damage caused by common carriers during shipment is not included in this guarantee.

This guarantee sets forth all applicable guarantees and remedies. No other warranty, expressed or implied shall apply. Failure to follow instructions found in Important Information Section of Owner Sheet shall void the guarantee. Consequential or incidental damages and or costs are not refundable.

# **Lumina Reversible**Assembly Instructions

READ THROUGH INSTRUCTIONS FROM BEGINNING TO END <u>BEFORE</u> STARTING TO ASSEMBLE UNIT.

- 1) Identify and Separate all the Parts and Hardware.
- 2.)To attach Hinge Pivot (G) to each side of Board Assembly (P-1), first remove the two factory installed screws in the board's clamp. Place Hinge Pivot (G) over holes and tighten screws back as shown in Illustration #1A.
- 3.) Insert the Board Assembly (P-1) between the two Legs (P-2) and connect using two Knobs (F) as shown in Illustration #1B. Leave the Knobs (F) loose.



3.) Attach the Top Cross Bar (P-3), it has two tapped Tray holes on one side of the tube, to the Legs (P-2) using four Screws (A) and tightening with Allen Wrench (D). Repeat this Step to attach the Bottom Cross Bar (P-4) to the Legs (P-2) using four more Screws (A) as shown in Illustration #2.





Illustration #2

### **Lumina Reversible**

4.) Tighten both Knobs (F) at this time. Attach Tray (P-5) to the Top Cross Bar (P-3) using two Screws (A) as shown in Illustration #3.



5.) Place a Lock Washer (H) on each Caster's threaded stem before attaching.

Screw in two Non-Locking Casters (B) and two Locking Casters (C) into the bottom of Legs (P-2) as shown in Illustration #4 and tighten with Caster Wrench (E).





Illustration #4





	#62387 #62382	#62390 #62383		
Α	74.5"	77.5"		
В	24"	24"		
C	36.5"	66.5"		