

44T800

Illustrated Parts List

Model Series

44T800

TYPE NUMBERS









0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010.

Not for
Reproduction











PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
10504-2 **Assemblies include all parts shown in frames.** **04/09/2014**




Not for
Reproduction

44T800




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 10504-4 Assemblies include all parts shown in frames. 04/09/2014




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 10504-5 Assemblies include all parts shown in frames. 04/09/2014




44T800



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
10504-6 *Assemblies include all parts shown in frames.* *04/09/2014*



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 10504-7 Assemblies include all parts shown in frames. 04/09/2014



44T800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	591695	Cylinder Assembly	36	694865	Spring-Valve (Exhaust)	209	798921	Spring-Governor (Orange)
2	797673	Kit-Bushing/Seal (Magneto Side)	42	499586	Keeper-Valve			----- Note -----
3	391086s	Seal-Oil (Magneto Side)	45	690977	Tappet-Valve			799171 Spring-Governor
4	797502	Sump-Engine	46	797242	Camshaft			(Light Blue)
5	799088	Head-Cylinder (Cylinder #1)	50	797503	Manifold-Intake			Used on Type No(s). 0002, 0003, 0004, 0005, 0007, 0008, 0010.
5A	799089	Head-Cylinder (Cylinder #2)	51	690949	Gasket-Intake			
7	693997	Gasket-Cylinder Head	51A	796876	Gasket-Intake			
8	792185	Breather Assembly	53	690951	Stud (Carburetor)			799169 Spring-Governor
9	690937	Gasket-Breather	54	699816	Screw (Intake Manifold)			(Dark Blue)
10	691108	Screw (Breather Assembly)	73	494439	Screen-Rotating			Used on Type No(s). 0009.
11	792184	Tube-Breather	74	698425	Screw (Rotating Screen)			
12	591911	Gasket-Crankcase	75	691056	Washer (Flywheel)	211	691019	Spring-Governed Idle (No Color)
13	793988	Screw (Cylinder Head)	93	845864	Collar-Throttle	212	695238	Link-Throttle
15	690946	Plug-Pipe (Oil Drain)	95	690718	Screw (Throttle Valve)	213	799510	Bracket-Control (Manual Choke)
16	796237	Crankshaft	98	699721	Kit-Idle Speed			Used on Type No(s). 0002, 0003, 0004, 0008, 0010.
		----- Note -----	104	694918	Pin-Float Hinge			----- Note -----
		796256 Crankshaft	105	797410	Valve-Float			799153 Bracket-Control
		Used on Type No(s). 0003, 0004, 0005.	108	699723	Valve-Choke			Used on Type No(s). 0001, 0005, 0006, 0007, 0009.
		796257 Crankshaft	117	842081	Jet-Main (Standard)			
		Used on Type No(s). 0008.	118	699733	Jet-Main (High Altitude)			
20	795387	Seal-Oil (PTO Side)	121	799132	Kit-Carburetor Overhaul	216	796229	Link-Choke
22	694966	Screw (Crankcase Cover/Sump)	122	798759	Spacer-Carburetor			Used on Type No(s). 0001, 0006, 0007.
23	799090	Flywheel	125	799109	Carburetor	216A	691022	Link-Choke
24	222698s	Key-Flywheel	130	690993	Valve-Throttle			Used on Type No(s). 0002, 0003, 0004, 0008, 0010.
25	792023	Piston Assembly (Standard)	131	799113	Kit-Throttle Shaft	216B	796879	Link-Choke
		----- Note -----	133	699724	Float-Carburetor			Used on Type No(s). 0005, 0009.
		792072 Piston Assembly (.020" Oversize)	135	699729	Tube-Fuel Transfer	217	799771	Spring-Choke Return
26	792026	Ring Set (Standard)	137	690994	Gasket-Float Bowl	219	793338	Gear-Governor
		----- Note -----	141	799112	Kit-Choke Shaft	220	799772	Washer (Governor Gear)
		792073 Ring Set (.020" Oversize)	142	796871	Nozzle-Carburetor	221	841026	Cup-Governor
27	690975	Lock-Piston Pin	150	841649	Gasket-Nozzle	222	798916	Bracket-Control (V3 Manual Choke)
28	696581	Pin-Piston	163	691001	Gasket-Air Cleaner			Used on Type No(s). 0002, 0003, 0004, 0005, 0008, 0009, 0010.
29	796209	Rod-Connecting	186	794873	Connector-Hose (Intake Manifold)	222A	592555	Bracket-Control (Choke-A-Matic)
32	690976	Screw (Connecting Rod)	186A	796532	Connector-Hose (Oil Drain)			Used on Type No(s). 0001, 0006, 0007.
33	793557	Valve-Exhaust	186B	799158	Connector-Hose (EVAP)	227	798856	Lever-Governor Control
34	793556	Valve-Intake	186C	845141	Connector-Hose (EVAP)			
35	694865	Spring-Valve (Intake)	187	791766	Line-Fuel (Cut to Required Length)			
			188	691108	Screw (Control Bracket)			
			192	690083	Adjuster-Rocker Arm			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 10504-9 Assemblies include all parts shown in frames. 04/09/2014

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
231	690718	Screw (Choke Valve)	404	690442	Washer (Governor Crank)	672	690234	Gasket- Carburetor Plate
239	697049	Switch-Oil Pressure	405	697820	Screw (Backplate)	691	790574	Seal-Governor Shaft
239A	792028	Switch-Oil Pressure Used on Type No(s). 0006, 0007.	411	698304	Screw (Air Cleaner Base)	697	591909	Screw (Drive Cap)
240	695666	Filter-Fuel	415	794903	Plug	703	691010	Clip
250	690957	Retainer-Breather	418	795912	Plate-Carburetor	718	690959	Pin-Locating
252	794389	Collector-Oil	431	799097	Elbow-Intake	726	499612	Gear-Ring
265	691024	Clamp-Casing	445	798897	Filter- Air Cleaner Cartridge	729	797454	Clip-Wire
267	792629	Screw (Casing Clamp)	447	691003	Screw (Air Guide Cover)	741	690980	Gear-Timing
276	695410	Washer-Sealing	448	799103	Bracket-Oil Cooler	742	690328	Retainer-E Ring
287	697820	Screw (Dipstick Tube)	467	790697	Knob-Air Cleaner (1" Long)	750	796208	Screw (Oil Pump Cover)
304	799957	Housing-Blower	474	592830	Alternator (10 - 16 Amp. Regulated)	789	695050	Harness-Wiring Used on Type No(s). 0001.
305	691005	Screw (Blower Housing)	493	797176	Bracket-Electronic Choke Module	789A	796860	Harness-Wiring Used on Type No(s). 0009.
305A	557049	Screw (Blower Housing)	496	799095	Lever-Air Cleaner Base	789B	797492	Harness-Wiring Used on Type No(s). 0005.
306	796852	Shield-Cylinder (Cylinder #1)	501	845907	Regulator	789C	591392	Harness-Wiring Used on Type No(s). 0001, 0004, 0008, 0010.
306A	591666	Shield-Cylinder (Cylinder #2)	505	691029	Nut (Governor Control Lever)	789D	591393	Harness-Wiring Used on Type No(s). 0003, 0006, 0007.
307	691003	Screw (Cylinder Shield)	512	796530	Hose-Oil Drain	789E	796914	Harness-Wiring Used on Type No(s). 0005, 0009.
307A	691108	Screw (Cylinder Shield)	523	691036	Dipstick	798	697890	Screw (Rocker Arm)
309	590476	Motor-Starter	524	691032	Seal-Dipstick Tube	829	799104	Hose-Oil Cooler
318	691127	Screw (Mounting Bracket)	525	691037	Tube-Dipstick	842	691031	Seal-O Ring (Dipstick)
318A	792629	Screw (Electronic Choke Module to Mounting Bracket)	526	691108	Screw (Regulator)	847	499602	Dipstick/Tube Assembly
332	691059	Nut (Flywheel)	552	796638	Bushing- Governor Crank	850	100106	Sealant-Liquid
333	592846	Armature-Magneto	552A	690553	Bushing- Governor Crank	865	591667	Cover-Air Guide (Valley)
334	691061	Screw (Magneto Armature)	562	690311	Bolt (Governor Control Lever)	868	690968	Seal-Valve (Rocker Cover)
337	491055s	Plug-Spark ----- Note ----- 792015 Plug-Spark Used on Type No(s). 0003, 0004, 0006, 0007, 0008, 0009, 0010.	563	799360	Screw (Debris Guard)	875	799094	Base-Air Cleaner
357	691483	Key-Pulley	573	593465	Plate-Back	883	690970	Gasket-Exhaust
358	799117	Gasket Set-Engine	601	691038	Clamp-Hose	914	691127	Screw (Rocker Cover)
363	19203	Puller-Flywheel	601A	841597	Clamp-Hose	918	797408	Hose-Vacuum (Length 3.2 Inches)
377	690979	Key-Woodruff	613	690341	Screw Muffler	918A	799160	Hose-Vacuum (Length 9.4 Inches)
383	19576s	Wrench-Spark Plug	615	698290	Retainer- Governor Shaft	929	794904	Screw (Air Cleaner Base Tab To Choke Bracket)
385	797409	Screw (Fuel Pump)	616	691045	Crank-Governor			
387	808656	Pump-Fuel	633	690722	Seal- Choke/Throttle Shaft			
400	796862	Cooler-Oil	635	692076	Boot-Spark Plug			
			640	796913	Thermostat			
			654	690958	Nut (Carburetor)			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
10504-10 Assemblies include all parts shown in frames. 04/09/2014

44T800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
934	592604	Screw (Fan Retainer)	1026A	690982	Rod-Push (Aluminum) (Intake)	1127	695407	Screw (Float Bowl)	
943	796222	Seal-O Ring (Oil Pump Cover)	1027	795890	Filter-Oil ----- Note -----	1128	690990	Screw (Carburetor Nozzle)	
947	798779	Solenoid-Fuel			798576	Filter-Oil	1169	690990	Screw (Carburetor Cover Plate)
949	799357	Cover-Static					Used on Type No(s). 0010.		
949A	593206	Screen-Debris Guard	1028	796864	Adapter-Oil Filter	1319	794467	Label-Warning	
964	799159	Cap-Connector	1029	690972	Arm-Rocker	1319A	797669	Label-Warning	
965	796221	Cover-Oil Pump	1029A	807323	Rocker Arm	1330	273521	Manual-Repair	
967	593217	Filter-Foam	1036		Label-Emissions (Available from a Briggs & Stratton Authorized Dealer)	1366	799131	Diverter-Oil Cooler	
968	799102	Cover-Air Cleaner				1373	695629	Screw (Oil Cooler Bracket)	
969	799093	Screw (Blower Housing Cover)	1054	280275	Tie-Cable	1373A	799105	Screw (Oil Cooler Bracket)	
975	799114	Bowl-Float/Solenoid	1058	279348TRI	Operator's Manual ----- Note -----	1374	796863	Seal-O Ring (Oil Cooler Diverter)	
987	808183	Seal-Throttle Shaft			279348WST	1406	799096	Valve	
997	592782	Cover-Blower Housing			Operator's Manual	1436	799108	Motor-Stepper	
1005	791236	Fan-Flywheel	1059	698516	Kit-Screw/Washer (Alternator)	1437	695239	Screw (Stepper/Bracket Motor)	
1006	798750	Retainer-Fan	1095	694013	Gasket Set-Valve	1438	796352s	Module-Electronic Choke	
1012	592556	Retainer-Link	1100	791959	Pivot-Rocker Arm	1439	794904	Screw (Thermistor Bracket)	
1013	690954	Nipple-Oil Filter	1119	691183	Screw (Alternator)				
1017	796214	Screen-Oil Pump	1124	841653	Seal-O Ring (Fuel Transfer Tube)				
1022	690971	Gasket-Rocker Cover	1124A	690988	Seal-O Ring (Fuel Transfer Tube)				
1023	793146	Cover-Rocker (Cylinder #1)	1126	690991	Screw (Fuel Transfer Tube)				
1023A	499600	Cover-Rocker (Cylinder #2)							
1024	796220	Pump-Oil							
1026	690981	Rod-Push (Steel) (Exhaust)							

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
10504-11 Assemblies include all parts shown in frames. 04/09/2014

Not for
Reproduction

