



INSTRUCTION MANUAL
CUSTOMER SERVICE: 1-800-645-2986

MODEL # 988946



It is the responsibility of the installer/user to read and understand all instructions and safety information before proceeding. If this product is used improperly or carelessly, the operator and/or bystanders might sustain serious personal injuries. Proper use and maintenance are essential for this product to function properly. Always use this product in accordance with the instructions in this manual.

Do Not exceed the maximum rated load.

Do Not stand or sit on the turntable or on the load at any time.

Loads **must not** extend over the shelves of the cart.

Loads **MUST** be centered on the turntable and stable.

Install **ONLY** on even, level surfaces.

Rotate turntable slowly with control.

Do Not modify the product in any way.

Do Not continue to use the machine if you observe abnormal motion or noise.

Keep the product clean & dry.

Always apply safety detent lock when not in use to restrict rotation.



Inspections & Maintenance

Before each use, inspect the listed components. At least once per month, inspect the turntable and all necessary components.

Turntable top and base - check each structure for bends, warps and cracks. Examine the turntable top for significant wear and impact damage.

Operate the turntable - rotate the table top; observe and listen for unusual noise or movement.

Product labels – make sure all Warning labels are visible on the unit.

Load bearings - Inspect the ball bearings and replace all bearing that are significantly worn.

Tracks - Examine the tracks of the turntable that guide the bearings. Remove dirt and all other debris from the tracks.