
# **ERGOTRON®**

### **LX Wall Mount System**



For the latest User Installation Guide please visit: www.ergotron.com



User's Guide - English Guía del usuario - Español Manuel de l'utilisateur - Français Gebruikersgids - Deutsch Benutzerhandbuch - Nederlands Guida per l'utente - Italiano Användarhandbok - svenska ユーザーガイド: 日本語

用户指南: 汉语








www.ergotron.com




USA 1-800-888-8458 Europe +31 (0)33-45 45 600 China 400-120-3051








## Components




## **Tools Needed**




## **Mounting Height for Ergonomic Workstation**


This mounting height is a recommendation for an ergonomic workstation that accommodates user heights of 5'0"-6'1" (152-185cm) when set up for standing and user heights of 5'0"-6'4" (152-193cm) when set up for sitting.


If user heights are different than this, you should change mounting height to accommodate user heights. (Change mounting height one inch for every one inch difference in user heights).




Mounting height assumes there is a 6" (152 mm) distance between the center of your monitor mounting holes and the top of the screen. If your distance is smaller, you should increase mounting height accordingly, if your distance is larger, you should decrease your mounting height accordingly.











### **Determine mounting location:**

Front view with arm pushed back against the wall.



Top view showing range of motion when pulled out from the wall.








WARNING: Ensure that the wall structure is capable of supporting four times the total weight of mounted equipment. Mounting to wall surfaces that do not meet this criteria may result in an unstable, unsafe condition which could lead to personal injury and/or property damage. Consult a construction professional if you have any doubt about what this means in regard to your particular application.




CAUTION: Make sure the wall mount bracket is level, flush and snug to the wall surface. DO NOT OVERTIGHT-EN THE BOLTS.



Wood Madera **Bois** Solide Holzbalkenträger **Massief Houten Pilaren** Due montanti in legno massiccio

Pernos de acero de calibre ≥ 25 Goujons ≥ calibre 25 en acier Bolzen ≥ Blechlehre Nr. 25 Verbindingsbouten ≥ 25 gauge staal Prigionieri in acciaio spessore ≥ gauge 25 (0,556 mm) Reglar ≥ 25-gauge stål



Pared Wand ≥ 5/8" Muur **Parete** 墙壁 Sheetrock Sheetrock Plaque de plâtre Rigipsplatte Sheetrock Cartongesso Gipsskiva シートロック 石膏板



**Hollow Wall** 

Mur

Requires minimum material thickness of 5/8" (16 mm). Requiere un grosor mínimo de 16 mm. Epaisseur minimum de 16 mm. Requer uma espessura mínima de 5/8" (16 mm). Mit einer Materialdicke von mindestens 16 mm.

Vereist een minimale materiaaldikte van 1.6 cm. Richiede uno spessore del materiale non inferiore a 16 mm. 厚さが最低 5/8" (16 mm) の資材が必要。 需要最低材料厚度为 5/8" (16 mm).

Madera Bois

Wood | Studs ≥ 25 gauge steel

Pernos de acero de calibre ≥ 25

Goujons ≥ calibre 25 en acier


Bolzen ≥ Blechlehre Nr. 25


Massief Houten Pilaren Due montanti in legno massiccio

Solide Holzbalkenträger


Verbindingsbouten ≥ 25 gauge staal Prigionieri in acciaio spessore ≥ gauge 25 (0,556 mm)


本 Reglar ≥ 25-gauge stål 25ゲージのスチールよりも強力なスタッド 大质 投端筋为不小于 25 标号的钢材








Bolzen ≥ Blechlehre Nr. 25 Verbindingsbouten ≥ 25 gauge staal Prigionieri in acciaio spessore ≥ gauge 25 (0,556 mm) Reglar ≥ 25-gauge stål 25ゲージのスチールよりも強力なスタッド 板墙筋为不小于 25 标号的钢材




































NOTE: Leave enough slack in cable to allow full range of motion.

Caution: To avoid the potential to pinch cables it is important to follow the cable routing instructions in this manual. Failure to follow these instructions may result in equipment damage or personal injury.





888-45-176-W-06 rev.U • 06/17





# 13 Adjustment Step

Important! You will need to adjust this product after installation is complete. Make sure all your equipment is properly installed on the product before attempting adjustments. This product should move smoothly and easily through the full range of motion and stay where you set it. If movements are too easy or difficult or if product does not stay in desired positions, follow the adjustment instructions to create smooth and easy movements. Depending on your product and the adjustment, it may take many turns to notice a difference. Any time equipment is added or removed from this product, resulting in a change in the weight of the mounted load, you should repeat these adjustment steps to ensure safe and optimum operation.












## How to remove this tilting feature:





### Set Your Workstation to Work For YOU!



### Learn more about ergonomic computer use at: www.computingcomfort.org

Height Position top of screen slightly below eye level.

Position keyboard at about elbow height with wrists flat.

Distance Position screen an arm's length from face—at least 20" (508mm). Position keyboard close enough to create a 90° angle in elbow.

Angle Tilt screen to eliminate glare.

Tilt the keyboard back 10° so that your wrists remain flat.

To Reduce Fatigue Breathe - Breathe deeply through your nose.

Blink - Blink often to avoid dry eyes Break • 2 to 3 minutes every 20 minutes

• 15 to 20 minutes every 2 hours.

For Warranty visit: www.ergotron.com/warranty

For Service visit: www.ergotron.com

For local customer care phone numbers visit: <a href="http://contact.ergotron.com">http://contact.ergotron.com</a>

Americas Sales and Corporate Headquarters	EMEA Sales
1181 Trapp Rd. St. Paul, MN USA (800) 888-8458 +1-651-681-7600 www.ergotron.com sales@ergotron.com	Amersfoort, The Netherlands +31 33 45 45 600 www.ergotron.com info.eu@ergotron.com
APAC Sales	Worldwide OEM Sales
Tokyo, Japan www.ergotron.com apaccustomerservice@ergo	www.ergotron.com info.oem@ergotron.com otron.com

### **ERGOTRON®**

While Ergotron, Inc. makes every effort to provide accurate and complete information on the installation and use of its products, it will not be held liable for any editorial errors or omissions (including those made in the process of translation from English to another language), or for incidental, special or consequential damages of any nature resulting from furnishing this instruction and performance of equipment in connection with this instruction. Ergotron, Inc. reserves the right to make changes in the product design and/or product documentation without notification to its users. For the most current product information, or to know if this document is available in languages other than those herein, please contact Ergotron. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written consent of Ergotron, Inc., 1181 Trapp Road, Eagan, Minnesota, 55121, USA Patents Pending and Patented U.S. & Foreign. Ergotron is a registered trademark of Ergotron, Inc.

© 2014 Ergotron, Inc. All rights reserved.