## **Enhanced EZH2O Error Codes**

Error Code	Error Description	Corrective Action
E001	Evaporator Thermistor Open Circuit	<ul> <li>Verify cable connector is plugged into control board (10 pin connector on harness # 0000001225)</li> <li>If error repeats, contact certified service professional</li> </ul>
E002	Evaporator Thermistor Short Circuit	<ul> <li>Check for excessive moisture on control board around 10 pin connector on harness # 0000001225</li> <li>If error repeats, contact certified service professional</li> </ul>
E003	Evaporator Low Temperature	<ul> <li>Unplug unit for at least 30 seconds and restart</li> <li>Monitor compressor for run-on condition</li> <li>If error repeats, contact certified service professional</li> </ul>
E004	Condenser Thermistor Open Circuit	<ul> <li>Verify cable connector is plugged into control board (10 pin connector on harness # 0000001225)</li> <li>If error repeats, contact certified service professional</li> </ul>
E005	Condenser Thermistor Short Circuit	<ul> <li>Check for excessive moisture on control board around 10 pin connector on harness # 0000001225</li> <li>If error repeats, contact certified service professional</li> </ul>
E006	Condenser Over Temperature	<ul> <li>Clean condenser if needed</li> <li>Check for proper fan operation (powers on, not obstructed, etc.)</li> <li>Contact certified service professional</li> </ul>
E007	Not Used	
E008	Not Used	
E009	Too Many Compressor Cycles	Contact certified service professional
E010	Not Used	
E011	Evaporator not cooling/Thermistor not measuring	Contact certified service professional

Error Code	Error Description	Corrective Action
E012	Bottle filler area obstructed	<ul> <li>Clean lens on IR sensor</li> <li>Unplug unit for at least 30 seconds and restart</li> <li>If error repeats, replace IR sensor with 1000002434 KIT - IR SENSOR</li> </ul>
E013	Missing or Incompatible Filter	<ul> <li>Check that filter is installed correctly (label facing forward, white tag facing back)</li> <li>Unplug unit for at least 30 seconds and restart</li> <li>Replace filter</li> <li>Replace filter head assembly with repair kit - 1000002030 KIT - FILTER HEAD-BRKT-FTGS</li> <li>If error repeats, contact certified service professional</li> </ul>
E014	Missing NFC Board	<ul> <li>Unplug unit for at least 30 seconds and restart</li> <li>Verify cable connector is plugged into NFC board on filter head assembly</li> <li>Verify cable connector is plugged into control board (10 pin connector on harness # 0000001225)</li> <li>Replace filter head assembly with repair kit - 1000002030 KIT - FILTER HEAD-BRKT-FTGS</li> <li>If error repeats, contact certified service professional</li> </ul>
E015	Missing LED Board	<ul> <li>Verify cable connector is plugged into LED board in the bottle filler tower assembly</li> <li>Verify cable connector is fully plugged into the basin from the tower assembly.</li> <li>Verify cable connector is plugged into control board (18 pin connector on harness # 1000001608)</li> <li>Replace LED filter status board with repair kit - 1000002436 KIT - ALPHA NUMERIC LED BOARD</li> <li>Replace tower cable harness – 1000001609 HARNESS-BASIN FEED TO BF</li> <li>Replace fountain cable harness – 1000001608 HARNESS-CNTRL BOARD TO BASIN FEED</li> </ul>