


## PRODUCT DATA SHEET

MELTBLOWN

Sonic Bonded - Yellow HazMat - Heavy Weight - Pads

### Item #: 1MBYPB


Basis Weight: 286 gsm\* Absorbency: 22 gal. oil and 16 gal. water\*\* Base Fiber: Polypropylene



ltem #	Color	Weight	Format	Size	Recycled content	Units/ case	Weight/ case***	LTL/ pallet	FTL/ pallet
1MBYPB	Yellow	Heavy	Pads	15″ x 18″	0	100	11 lbs.	30	36

#### DESCRIPTION

- Versatile yellow HazMat sorbent for cleaning up aggressive and unknown chemicals
- A single layer of polypropylene fibers bonded "sonically" together
- Designed to absorb a wide range of toxic, flammable, corrosive and aggressive chemical spills
- Very fine, uniform-sized fibers increase loft and absorbency
- Perforated for easy use



#### **KEY FEATURES**

- Yellow color code signals emergency use
- Great value, versatility and reliable performance
- Very fast wicking, which reduces the clean-up time
- Dimpled surface reduces lint, increases strength and speeds absorption
- Combines high loft with drapability

#### APPLICATION

The go-to sorbent for emergency spill response. A great choice to safely clean up a wide range of toxic, flammable, corrosive and aggressive chemical liquids. Use them anytime there is a spill of an unknown liquid.

#### NOTES

- Be aware of compatibility of chemicals when using this product
- Ensure that disposal of these sorbents complies with all local, state and federal regulations
- \* Basis weights and recycled content are ± 5%
- \*\* Measures a case/bale using ASTM 726 (long test) with medium viscosity oil and tap water. Statistical average derived from real time production QC data.
- \*\*\* Weight per case ± 1 lb.

#### COMPLIANCE

<b>RELATED REGULATIONS</b>	DESCRIPTION
29CFR 1910.22(a)(2)	"The floor of every workroom shall be maintained in a clean and, so far as possible, a dry condition."
29CFR 1910.120(j)(1)(vii)	" suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks or ruptures may occur."
29 CFR 1910.1450	Laboratories must have containment and clean-up materials for spills and leaks to reduce occupational exposure to hazardous chemicals.
40 CFR 263.31	Transporters "must clean up any hazardous waste discharge that occurs during transportation."

# MELTBLOWN